

## BT Voyager 2110 Realm Change Guide.

1. Start your Internet Browser and in the address bar type the following IP address **http://192.168.1.1/vpivci.html**
2. When prompted, enter the following details and click **OK**.

User Name: **admin**

Password: **admin**

\*If you previously changed the router configuration password, use the password you set instead of **admin**.

3. The Configure ATM PVC screen appears. No changes are required, click **Next**.
4. The Configure Connection Type screen appears. No changes are required, click **Next**.
5. The Configure WAN IP Settings screen appears. No changes are required, click **Next**.
6. The Configure Broadband User Name and Password screen appears as below. Delete all of the letters to the right of the "@" symbol, replace them with **talktalkbb** and click **Next**.

### Quick Setup

#### Configure Broadband User Name and Password

To use your Broadband service, please verify your Broadband user name and password.

Broadband User Name:	<input type="text" value="TalkTalk12345@talktalkbb"/>
Password:	<input type="password" value="••••••••"/>
Session established by:	<input checked="" type="radio"/> Always On
	<input type="radio"/> Dial on Demand
	Disconnect if no activity for <input type="text" value="20"/> minutes
	<input type="radio"/> Manually Connect
	Disconnect if no activity for <input type="text" value="20"/> minutes

< Back

Next >

7. The Configure LAN side Settings screen appears. No changes are required, click **Next**.
8. A summary screen appears. Click **Finish**. Your broadband modem will restart automatically. Please allow up to **5 minutes** for this to happen. After the modem has restarted, you will be shown a connection status screen similar to the screenshot below, stating that you are now **connected**.

#### Connection Status

[Refresh](#)

**Online Time** 17 hours 11 mins 20 secs

**Data Transmitted** 79275552 bytes

**Data Received** 767020272 bytes

More details can be found in the [Advanced...|Status](#) menu.